


Spare parts suitable for:
ALPENINOX



A Open tops (gas)

Suitable for Alpeninox



Item	Order	Description	Model	OEM
1	103051	burner cover, 80mm	700 series	A2094
2	104082	burner base		A2168
3	104086	Venturi		A2092



Item	Order	Description	Model	OEM
1	103052	burner cover, 125mm	700 series	A2100
2	104083	burner base		A2165
3	104087	Venturi		A2098



Item	Order	Description	Model	OEM
1	101491	gas tap	700 series	A2163
2	111731	knob		A2468
3	102008	thermocouple, 1000mm		52163



Item	Order	Description	Model	OEM
1	100706	electrode	700 series	56754
2	101007	ignition unit (2 outputs)		A2073
3	101010	ignition unit (7 outputs)		A2097



Item	Order	Description	Model	OEM
1	103051	burner cover, 80mm	900 series	A2094
2	104084	burner base		A2093
3	104086	Venturi		A2092



Item	Order	Description	Model	OEM
1	103052	burner cover, 125mm	900 series	A2100
2	104085	burner base		A2099
3	104087	Venturi		A2098



Item	Order	Description	Model	OEM
1	101086	gas tap	900 series	A2001
2	111736	knob		A2460
3	102045	thermocouple, 1500mm		56840



Item	Order	Description	Model	OEM
1	100044	pilot burner	900 series	27073
2	100706	electrode		56754
3	101007	ignition unit (2 outputs)		A2073
4	101010	ignition unit (7 outputs)		A2097



Item	Order	Description	Model	OEM
1	300074	switch	700 series,	A2227
2	111737	knob	900 series	A2465


Open tops (solid top)



Item	Order	Description	Model	OEM
1	n.l.a.	burner	720-_, 760-__	A2406
2	n.l.a.	burner	740-__	A2257
3	n.l.a.	burner	20TP_	A2256
4	105771	burner	40TP_, 60TP_, 80TP_	A2132



Item	Order	Description	Model	OEM
1	101397	gas tap	720-_, 760-_,	A2165
2	111735	knob		A2469
3	101086	gas tap	740-_, 20TP-_, 40TP-_, 60TP-_, 80TP-_,	A2001
4	111736	knob		A2460



Item	Order	Description	Model	OEM
1	102045	thermocouple, 1500mm	720-_, 760-_, 740-_,	56840
2	100044	pilot burner	20TP-_, 40TP-_, 60TP-_, 80TP-_,	27073
3	100706	electrode		56754




Item	Order	Description	Model	OEM
1	300074	switch	720-_, 760-_, 740-_,	A2227
2	111737	knob	20TP-_, 40TP-_, 60TP-_, 80TP-_,	A2465
3	101007	ignition unit		A2073

Open tops (electrical)



Item	Order	Description	Model	OEM
1	490065	2000 W/230 V	700 series	A2198
1	490066	2600 W/230 V		A2199
2	490054	2500 W/230 V	900 series	A2020
2	490071	4000 W/230 V		52199




Item	Order	Description	Model	OEM
1	300025	switch	700 series, 900 series	A2021
2	300106	switch	900 series	A2022
3	110362	knob	700 series, 900 series	alternative A2462
4	110605	symbol		
5	359378	signal lamp		A2224

Ovens (gas)




no longer available


Item	Order	Description	Model	OEM
1	n.l.a.	burner	700 series	A2170
2	105773	burner	900 series	A2474



Item	Order	Description	Model	OEM
1	101132	Minisit controller		51567
2	101136	piezoelectric igniter and cover	700 series, 900 series	51567
3	110068	knob		54268
4	100026	ignition cable, 1000 mm		54273



Item	Order	Description	Model	OEM
1	102045	thermocouple, 1500mm	700 series	56840
2	100044	pilot burner		27073
3	100706	electrode		56754




Item	Order	Description	Model	OEM
1	102045	thermocouple, 1500mm	900 series	56840
2	100109	pilot burner		A2472
3	100701	electrode		A2473

Ovens (electric)




no longer available

Item	Order	Description	Model	OEM
1	n.l.a.	2400 W/230 V	700 series	A2200
2	415093	900 W/230 V	900 series	A2133



Item	Order	Description	Model	OEM
1	375412	thermostat	700 series	A2206
2	300001	switch		A2036
3	110362	knob		Alternativ A2250
4	110615	symbol		A2224
5	359378	signal lamp		




Item	Order	Description	Model	OEM
1	390076	thermostat	900 series	A2206
2	300002	switch		A2134
3	111734	knob		A2588
4	359378	signal lamp		A2224

Ovens (mechanical)



Item	Order	Description	Model	OEM
1	700006	hinge/right	700 series 900 series	A2005
2	700007	hinge/left		A2004
3	700001	body section		53096

Fry tops (gas)



Item	Order	Description	Model	OEM
1	101397	gas tap	700 series	A2169
2	111735	knob		A2469
3	102045	thermocouple, 1500mm		56840




Item	Order	Description	Model	OEM
1	100044	pilot burner	700 series	27073
2	100706	electrode		56754
3	101007	ignition unit		A2073




Item	Order	Description	Model	OEM
1	101086	gas tap	900 series	A2001
2	111736	knob		A2460
3	102045	thermocouple, 1500mm		56840


Bain-Marie (electric)



Item	Order	Description	Model	OEM
1	415096	550W/230 V	700 series	A2197
2	415097	800W/230 V	900 series	A2137



Item	Order	Description	Model	OEM
1	375055	thermostat	700 series	A2018
2	300001	switch		A2036
3	111732	knob		A2461
4	359378	signal lamp		A2224



Item	Order	Description	Model	OEM
1	375143	thermostat	900 series	A2237
2	111732	knob		A2461
3	300017	switch		A2241
4	111733	knob		A2464


Fryers (gas)



Item	Order	Description	Model	OEM
1	101131	Minisit controller	700 series	56688
2	101136	piezoelectric igniter and cover		51567
3	110068	knob		A2172
4	100026	ignition cable		54273




Item	Order	Description	Model	OEM
1	100109	pilot burner	900 series	A2472
2	100701	electrode		A2473
3	100007	piezoelectric igniter		A2073



Item	Order	Description	Model	OEM
1	300074	switch	700 series,	A2227
2	111737	knob	900 series	A2465


Fry tops (electric)



Item	Order	Description	Model	OEM
1	415100	1500W/230 V	720-__	A2070
2	415099	1500W/230 V	740-__	A2208
3	415098	1500W/230 V	900 series	A2247, A2068




Item	Order	Description	Model	OEM
1	390076	thermostat	700 series,	A2206
2	300002	switch		A2134
3	111732	knob		A2461
4	359378	signal lamp		A2224




Item	Order	Description	Model	OEM
1	100044	pilot burner	700 series	27073
2	100706	electrode		56754
3	102070	thermocouple, 1000mm		54055
4	390062	safety thermostat		A2011



Item	Order	Description	Model	OEM
1	101123	Elettrosit gas valve	900 series	A2035
2	101312	interrupter		54539
3	101007	ignition unit		A2073




Item	Order	Description	Model	OEM
1	100044	pilot burner	900 series	27073
2	100706	electrode		56754
3	102250	thermocouple, 1000mm		51932, 56914
4	390062	safety thermostat		A2011



Item	Order	Description	Model	OEM
1	390058	thermostat	900 series	A2003
2	300001	switch		A2036
3	111732	knob		A2461
4	359378	signal lamp/green		A2224
5	359379	signal lamp/yellow		A2225

Fryers (electric)



Item	Order	Description	Model	OEM
1	390058	thermostat	700 series, 900 series	A2003
2	300002	switch	700 series	A2134
3	300001	switch	900 series	A2036



Item	Order	Description	Model	OEM
1	111732	knob	700 series, 900 series	A2461
2	359378	signal lamp/green		A2224
3	359379	signal lamp/yellow		A2225
4	390064	safety thermostat		A2204

Fryers (mechanical)



Pos.	Order	Description	Model	OEM
1	970419	290x285x125mm	700 series, 900 series	A2603

Tilting bratt pans (gas)




Item	Order	Description	Model	OEM
1	105646	burner	700 series	56796
2	105772	burner	900 series	A2139



Item	Order	Description	Model	OEM
1	101132	Minisit controller		56833
2	101136	piezoelectric igniter and cover		51567
3	110068	knob	700 series	54268
4	100026	ignition cable, 1000mm		54273




Item	Order	Description	Model	OEM
1	100044	pilot burner		27073
2	100706	electrode	700 series	56754
3	102045	thermocouple, 1500mm		56840



Item	Order	Description	Model	OEM
1	101123	Elettrosit gas valve		A2035
2	101312	interrupter	900 series	54539
3	101310	extension/knob on		A2618
4	101311	extension/knob off		A2617



Item	Order	Description	Model	OEM
1	100044	pilot burner		27073
2	100706	electrode	900 series	56754
3	102045	thermocouple, 1500mm		56840
4	101007	ignition unit		A2073




Item	Order	Description	Model	OEM
1	375202	thermostat		A2012
2	111734	knob	900 series	A2588
3	359378	signal lamp/green		A2224
4	346362	micro switch		A2145




Item	Order	Description	Model	OEM
1	346338	0-I-switch		A2233
2	346367	push button/water	900 series	A2234
3	346366	push button/arrow		A2232
4	346340	switch		A2196


Tilting bratt pans (electric)



Item	Order	Description	Model	OEM
1	415098	1500W/230V	700 series, 900 series	A2068
2	375202	thermostat		A2012
3	300074	switch	700 series	A2162
4	359378	signal lamp/green		A2224



Item	Order	Description	Model	OEM
1	110360	knob		alternative A2820
2	110615	symbol	700 series	
3	110362	knob		alternative A2464
4	110604	symbol		



Item	Order	Description	Model	OEM
1	375202	thermostat	900 series	A2012
2	111734	knob		A2588
3	359378	signal lamp/green		A2224
4	346362	micro switch		A2145



Item	Order	Description	Model	OEM
1	346338	0-I-switch	900 series	A2233
2	346367	push button/water		A2234
3	346366	push button/arrow		A2232
4	346340	switch		A2196


Boiling pans (gas)



Item	Order	Description	Model	OEM
1	101092	gas tap	900 series	S2146
2	111736	knob		A2460
3	102072	thermocouple		A2161



Item	Order	Description	Model	OEM
1	100044	pilot burner	900 series	27073
2	100706	electrode		56754
3	101007	ignition unit		A2073




Item	Order	Description	Model	OEM
1	300074	switch	900 series	A2227
2	111737	knob		A2465

Boiling pans (electric)



Item	Order	Description	Model	OEM
1	418079	4500W/230 V	900 series	A2484
2	418080	6000W/230 V		A2485
3	510409	gasket		-



Item	Order	Description	Model	OEM
1	380015	energy regulator	900 series	A2482
2	301141	switch		A2486
3	110362	knob		alternative A2463
4	110608	symbol		
5	359378	signal lamp/green		A2224
6	359380	signal lamp/red		A2408



Item	Order	Description	Model	OEM
1	375623	safety thermostat	900 series	A2483
2	541350	pressure switch		A2480
3	n.l.a.	relay		A2769